AIM: - Configuring DHCP within a LAN in a packet tracer. Topology: router 0 10.0.0.2 Switch 803/1 Ba 1/1 Ba 2/1 FaO Fao FaO PCI PCO PC 2 somer 10.0.0.1

Drock dure: -Place 3 PC's, one router, one generic switch, one server and connect everything with copper straight wire. Place note 10.0.0. 2 for router indicating gateway and 10.0.0.1 for server indicating its IP address Interface the corresponding fastethornot interface for souter using CLI :-→ enable -> config t > interface fast ethernet 3/0 > ip address 10.0.0.2 255 0.0.0 - no Shut * Now configure server by elicking services tal c review mi -> set default gateway -> set DNS server -> set starting IP address as 10.0.0.3 -> Mox. no of users is 8 -> TETP somer as 10.0.0.1 -> Then relick on save. * Then click on PCO, go to desktops like on Il configuration and you click on DHCP. when we select DHCP mode, it automatically abservations: fetches, gateway from server for which we had configured already.

Kesulti
ping 10.0.0.5

pinging 10.0.0.5 with 32 bytes of data:
Reply from 10.0.0.5, bytes=32 time=1ms 17 L=128

Reply from 10.0.0.5, bytes=32 time=0ms 17 L=128

Reply from 10.0.0.5, bytes=32 time=0ms 17 L=128

Reply from 10.0.0.5, bytes=32 time=0ms 17 L=128

Ping statistics for 10.0.0.5;

Packets 2ent=4, Received=4, Loss=0 (0.1. Loss)